

# SUNVISOR INSTALLATION INSTRUCTIONS

Note: These sunvisors are designed to install and function with set screw.

1. Slide old sunvisor off of mounting bracket by removing the set screw and twisting the sunvisor while pulling it off of the mounting pin. Insert the mounting pin into the sleeve end of the new sunvisor and gently push and twist until the sunvisor slides into place on the mounting pin.

2. Transfer mirror if present:

A template is enclosed with the new sunvisors for use in transferring the GM mirror to the new sunvisor. Use the template to mark the holes where the mirror attaches on the new sunvisor. Then carefully make a small slit or hole in the sunvisor fabric where the mirror mounting posts will be inserted. Then align the mirror mounting posts with the holes in the sunvisor and carefully press the mirror toward the sunvisor until the mirror mounting posts snap into place in the sunvisor, attaching mirror firmly to the sunvisor.

3. New Flip Up Door Mirrors are available for each visor at an extra cost. Mirrors are approximately 7" x 2-1/2", and are available in Dark Charcoal Plastic Only. They must be ordered at the same time the sunvisors are ordered.