

## Mazda RX-7 Drain Hose Attachment Instructions

Included with your Convertible Top is the following:

- 2 – Grommets with bezel and Flat Washers
- 1 – Tube Instant Krazy Glue
- 2 – Five (5) Foot Lengths of ½” diameter Clear Drain Hose

Your Convertible Top has one drain pocket on both sides of the top. A hole is pre-punched with the location for the Drain Hose attachment.

First, attach the top part of the grommet with bezel through the hole on the top side of the material. Then attach the washer over the flange on the back side of the material sandwiching the material between both parts of the grommet.

Second, put some Krazy Glue around the flange of the grommet and push one end of the hose over the flange and flush against the back side of the grommet compressing the material tightly between both sides of the grommet. The glue should set within a few minutes.

Finally, we recommend clear, silicone caulking (not included) smeared around the washer on the underside of the top to remove any chance of water seepage.

