

Amigo Instructions

Installation Procedures:

1. Snap Stud Installation: You will need to remove the two screws holding down the rubber seal immediately to the left and to the right of the tailgate.
2. Top installation: Snap center snap #1 on top to center stud on top of the vehicle. Pull top to the side and secure snap #2 to stud. Tuck seal into place and secure snaps between #1 and #2 to studs on vehicle. Secure snaps 3 and 4 to studs on vehicle. Tuck seal into place and secure snap between 3 and 4 to stud. Secure snaps 5 and 6 to studs on vehicle. Tuck seal into place and secure snaps to studs between 5 and 6. Repeat for the other side. When removing these types of snaps you must first pull down, then left to remove them. Snap rear bow flap into place. Place rear curtain into position and secure with turn fasteners.

Note: On some early models there are turn fasteners all the way across the tailgate. If this is the case on your vehicle, you will need to remove one from each end of the tailgate and install a snap stud included in the parts kit. Place screw through the snap stud, the tailgate and secure with hex nut.

Rolling up side panels:

It is possible to roll up your side panels or rear curtain to provide more ventilation in your vehicle. Prior to rolling side panels or rear curtain you must first make sure that windows are clean. If not properly cleaned dirt will scratch them reducing top life. It is also recommended to place a cloth between the glass and the retaining straps to prevent the straps from marking the glass. To clean windows, wash them with a mild non-detergent soap and water. To roll up side panel, unzip rear curtain zippers, unsnap side panels, fold rear of side panel forward and roll up side panels. Secure with retaining straps on top. To roll up rear curtain follow the same procedure. You may roll up both side panels and rear curtain if you wish.