

Installation Instructions for Part No. C-675SC, VW Thing Side Curtains

Punch out or drill out rivets holding metal brackets to frame. Rivets should come out with a flat head punch tool. (You may have to soak bracket in WD-40 for a few minutes.)

Remove old curtains, snaps, etc., leaving the bare metal frame.

Insert metal frame into new curtain that will be attached to frame with Velcro all the way around as pictured.

Note: Before completely fastening Velcro around metal frame, mark the location where the brackets will be re-attached. Brackets will be re-attached with machine screws/bolts and nuts.

