

ISUZU AMIGO INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Pliers, standard screwdriver and Philips screwdriver

TIPS: For ease of installation the top should be installed when the temperature is above 72 degrees Fahrenheit. In colder temperatures the top may contract as much as an inch making the installation more difficult.

It is normal for the top to contract and wrinkle following storage in the shipping box. Once the top has been on the vehicle for a few days the wrinkles will disappear and the top will form to the vehicle.

Remove old top while carefully observing where everything is located.

Next install the snap studs found in the small plastic bag included with top. Remove the two screws holding down the rubber seal immediately to the left and right of the tailgate. Replace these screws with the snap studs by putting the machine screw through the snap stud and place the washers below the snap studs. Then push the assembly through the rubber seal and the body of the vehicle and attach with the hex nuts.

There are nine Female Common Sense Fasteners installed on the bottom of the rear roll up window. Included in the hardware kit are (9) Male Common Sense Fasteners and (18) 3/32" Phillips head machine screws. You will need to remove your old fasteners from the top of the tailgate and install the enclosed Male Common Sense Fasteners. Using the Female fasteners in the bottom of the window for a template, mark the Male fastener locations with a grease pencil. Then, mark the two holes for each fastener and drill 1/16" holes.

NOTE: In order to install all nine (9) Male fasteners in the correct location it is recommended that you also draw a straight line across the top of the tailgate where the fasteners are to be installed. This will help insure a more even attachment when the rear window is secured.

Snap the center snap on the top to the center stud on the top of the vehicle. Then work to each side one snap at a time being careful to tuck the seal into its proper place before snapping each stud. Next snap rear bow flap into place on the snaps that you installed.

Then place the rear curtain into position and secure with the turn fasteners from your vehicle. On some early models there are turn fasteners all the way across the tailgate. If your vehicle is one of these you must remove one of the turn fasteners from each end of the tailgate and install the two snap studs provided as described above.