

PLEASE NOTE: (for C-732, C-734 and C-930 Top installation)

When installing your top you need to pay special attention to installing the rubber tube at the bottom of the back window curtain into the channel section on your vehicle.

Do not attach this rear window section to the rest of the top or install it on the vehicle until you have removed the channel from your vehicle and installed it onto the rubber tubing at the bottom of the back window section of the top.

This channel should be very clean and not have any sharp projections so the rubber tube will easily slide into position without damaging the top.

The best way to install the rubber tube into the channel is to lay a towel or soft cloth on a table or workbench and then lay the rear window section flat on the towel to prevent scratching the plastic window. Then gently slip the channel into place while holding the window flat.

This should not be difficult to do. If it seems difficult, stop and try to figure out what is causing the problem. Forcing the channel into place roughly can damage the top and void the warranty.

Once the channel is installed over the rubber tube and the rest of the top is installed on the vehicle you can snap the channel back into place on the vehicle and zip the rear window section into place on the vehicle.