

Jun-02

## 1990-1997 & 1999-2002 Mazda Miata Convertible Headliner

### Installation Instructions for Part Number ACH-60 and ACH-61



Prior to beginning installation it is recommended to soften the black plastic bow retainers by putting the headliner in the sun or using a hair dryer to soften the retainers.

- 1 Bow #1 (first bow located approx 8" behind front header). On back side of headliner are two black plastic bow retainers. Center headliner in roof from side to side and snap the first plastic bow retainer over bow #1. Note: Rear of headliner has a velcro flap.
- 2 Bow #2 (behind first bow). Center in roof from side to side and snap plastic over bow.
- 3 Front Header - remove trim molding covering edge of metal. Apply two sided tape on bottom edge of metal. (Two sided tape included in kit)
- 4 Attach front edge of material to the area where the two sided tape is applied starting from the center and working outward on both sides. Then re-attach trim molding back over edge of metal and material.
- 5 Bow #3 - (rear bow above window) Un-do the velcro holding the inside of the top to the bow. Attach the strip (included in kit), to the velcro on inner roof sleeve.
- 6\*\* Install Bow Sleeve on rear header bow (bow #3). Attach the back edge of the headliner to the velcro sleeve starting in center and working outward from the center.
- 7 There are "J" plastic attachments sewn to the inside of the headliner around the window area. Snap these into place over the metal frame.
- 8 Front of flaps on both sides that cover the metal frame have a velcro section sewn into each side with a piece of adhesive back velcro attached. Remove protective tape from the back side of the velcro and press flap into place on the frame.

Note: When putting top up and down the "J" plastic attachments around window area will come loose. After top is put back up, snap "J" plastic back into place.

\*\* Separate Bow Sleeve is only required on ACH61 - 1999-2002 Model