

# Very Important

## SUV Top Installation Instructions for Tracker, Sidekick, Vitara, Amigo, Samarai, Kia

### Before Installation

**The top should be laid out flat, outside in sunny weather, under the sun for a minimum of 2 hours, or in a heated room overnight. This allows the vinyl to loosen up and stretch properly during installation.**

The top should be installed at temperatures above 72 degrees Fahrenheit. Below this temperature, the top material may contract an inch or more making it very difficult to install and could even tear the seams and stitches.

These instructions are basic to the SUV Tops, **and are designed to be a guide only**, They should allow you to generally find your way around an installation, but are not specific. Your SUV may differ a little from these instructions.

Our products are made similar to the original so, we cannot be responsible for damages due to incorrect installation of the top, window, hardware or any other related component.

**Prior to beginning installation** please check your order to be sure that everything is correct, i.e., year, make, model, color, material, etc. If we sent you the wrong item, we will gladly accept it back for credit and ship you the correct item, providing the incorrect item is returned in saleable condition. No credit will be issued for incorrect items if installation has been started.

Before you remove your old top, lay your new top over it to check fit. It may seem a little small as it is lying over the current top.

**Suggestion:** Remove original top carefully, noting installation and use old top as a reference while installing your new top.

For best results when installing SUV tops, it is suggested to start as follows:

First attach all inside fasteners and then start in the back and work forward. Begin in the center and work your way out to each side. For example, if a top has snaps or other types of fasteners, to attach the center fastener and then one toward the passenger side. Then go to the driver side and rotate back and forth until all fasteners are attached. Also, zip in the side windows before latching the center deck in front. New tops fit tight and once the windows are zipped in then latch the top.

**Note:** The finished top is going to fit tight and will need to stay in the up position for approximately two weeks prior to retracting in order for the material to take on the natural shape of the frame. This is especially true in colder climates.